

NOTE: this is a supplement instruction document showing the retrofit of a Kurt Version fixture; reference the particular Fixture mounting instructions to complete the installation.

1. Turn off power to fixture.
2. Remove existing lamp from socket
3. Install the E11 to E12 adaptor into lamp socket, then install the E12 to Wire Lead Adapter into the E11 to E12 Adapter
4. Attach ground wire to can body with supplied Ground Screw
5. Insert mounting plate into can, allowing it to rest on ledge (Mounting plate may be broken at slits to accommodate internal can diameter.)
6. Make electrical connections to light fixture as per the "Electrical Installation" section of the Installation Instructions
7. Attach Silescent Fixture to direct to the mounting plate with supplied hardware (*reference corresponding Silescent Fixture for additional Installation Instructions*).

Figure 1: Kurt Versen Retrofit

